



PC Live software


Turn any Vaetrix gauge into a live datalogger using most Windows PC's. Just download the software from the website and connect the USB to any Vaetrix product. Registration is required to use the product.

Use your PC and eliminate the chart and pens from your chart recorder



Key Features

- Live streaming with multi-color graph, digital pressure, and temperature data
- Report builder with job info, notes, attachments, test windows, and ability to zoom
- Create and send professional .pdf reports in a matter of minutes with NIST traceable encrypted results without additional software
- Monitor data from multiple devices at one time!



Distributed by

www.trincalservices.com

45 Bramalea Rd Unit 204, Brampton, Ontario L6T 2W4
Email: sales@trincalservices.com | Phone: 1-855-874-6225 (1-855-TRINCAL)



PC Live software

Parameter	Specifications (Consult Manual for Complete Details)
Data Reporting Interval	Selectable from 1x minute to every hour
PC Requirements	Windows 10 or greater, 1 GB RAM, 1 GHz or faster, Hard Disk of 16 GB or greater, and Adobe Acrobat
PC Connection	USB A 2.0 and Greater
Temperature	14°F to 122°F (-10°C to 50°C) Compensated operating range -10°F to 150°F (-23°C to 65°C) Storage (remove batteries over thirty days)

Part Number Configurator:
VaeTriX PC Live = VX-AS00103
 (Consult factory for multiple gauge discount structure)



Accessories:

VX-WC00102	6ft USB to Micro B Cable (Right Angle -ETG and HTG)
VX-WC00104	6ft USB to Printer Style (HTGX and DCR)
VX-CA00002	Rover USB Extender (Define length up to 150')



Distributed by

www.trincalservices.com

45 Bramalea Rd Unit 204, Brampton, Ontario L6T 2W4
 Email: sales@trincalservices.com | Phone: 1-855-874-6225 (1-855-TRINCAL)